

Model VX0 Horizontal Feet Kit Installation Instructions

Use the following instructions to mount the thin client to the horizontal feet kit.



1. Rotate the thin client until the power button is to the right of the front connectors; position the horizontal feet onto the left and right spines of the thin client and slide them toward the front until they snap in place. The first feet snap twice, once over the first locator position and then again at the second locator position.



Note

Leave at least 12.5 mm between the ventilation holes of the thin client and any solid surface. An enclosed area must have a minimum of 150 square cm of venting or other open area to maintain proper ventilation of the thin client.